

Dear Customer,

Thank you for your purchase of a Sharper Image Design™ product. You have received a quality product, backed with a one-year warranty. Your satisfaction as a Sharper Image customer means everything to us. We look forward to serving you now and in the future.

Many other affordable, fun, and useful products are available through The Sharper Image® catalog, sharperimage.com, and The Sharper Image® retail stores. To receive a copy of our catalog or for the address of the store nearest you, please call our toll-free number 1-800-344-4444.

Enjoy your purchase!

*Richard*  
Richard Thalheimer  
Founder and Chairman

**www.sharperimage.com**

Shop our complete Internet catalog.  
Online ordering is protected by  
Secure Sockets Layer technology.

### FULL ONE-YEAR WARRANTY

**What is Covered**

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

**How Long Coverage Lasts**

This warranty runs for one year from the date of original purchase.

**What is Not Covered**

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or replacement of batteries.

**What The Sharper Image Will Do**

The Sharper Image will either repair any defects in materials or workmanship, or exchange the defective unit with a reconditioned unit. In the event repair or exchange is not possible, The Sharper Image will either replace this product with one of similar features and price, or refund the full purchase price of the product, whichever you prefer.

**How to Obtain Service**

Return the product and receipt, along with a brief explanation of the problem, to:

T.S.I. - Returns Department  
2901-A West 60th Street  
Little Rock, AR 72209

**If you have questions**

Please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

Copyright 2001 Sharper Image Corporation


Printed in China  
IMV3

**THE  
SHARPER  
IMAGE®**

**Big Digit  
Alarm Clock**

SI415 Instructions


**SHARPER IMAGE DESIGN™**




Batteries and Power Requirements

The Big Digit Alarm Clock requires one CR2032 battery (included) to operate the clock. The alarm, backlit screen and flashlight are powered by six AA alkaline batteries or an AC adapter (both purchased separately).

Slide battery covers off the back of the unit to access the battery compartments.



Operating Instructions



**If the clock display appears dim or hard to read:**  
Replace the CR2032 battery.

**If the clock ever malfunctions or the display “locks up”:**  
Use the tip of a pen or unbent paper clip to press the reset button, located under the AA battery cover.

**RESET BUTTON**

**DISPLAY SWITCH**  
AM/PM  
24-Hour

**To switch clock for 24-hour display (military time):**  
Use the tip of a pen or unbent paper clip to slide the display switch, located under the AA battery cover. Press RESET to finalize.